



Assembling the IKEA *Mammut* Children's Chair

The following instructions are your guide to assembling the IKEA *Mammut* children's chair.

Note: For extra support during assembly, don't hesitate to call IKEA Customer Service at 1 (888) 888 4532. A representative would be happy to help you along in the assembly process.

What's in my IKEA *Mammut* Children's Chair Package?

Piece A: Square Seat (x1)

A1- Side A1 has three slots (A1A) along one of its edges

A1A- Set of three slots on side A1

A2- Side A2 has a leg hole (A2A) in each corner

A2A- Leg holes on side A2

Piece B: Hollow Leg (x4)

B1- Narrow end of Leg (B)

B1A- Line along B1

B2- Wide end of Leg (B)

B2A- Wedge inside B2

Piece C: Leg Cap (x4)

C1- Slit in Leg Cap (C) rim

Piece D: Wooden Block (x1)

Piece E: Backrest with Slats (x1)

E1- Side of slats with a protruding peg



What you'll need:

A hammer

A clear space

Soft ground to work on.

Why? Assembling your IKEA Mammut children's chair directly on hard ground like tile or concrete could damage your pieces. It is best to work on carpet or a large rug.

Part I. Assembling the seat and legs.

1. Unpack the square seat (A), four legs (B), and four leg caps (C) from your IKEA package.
2. Lay the seat (A) on the ground so that side A2 is facing up.
3. Insert narrow leg end (B1) into corner leg hole (A2A).
4. Repeat 3 more times until all narrow leg ends (B1) are in a corner leg hole (A2A).

Note: Align line B1A with the arrow at each leg hole (A2A). This will guarantee the stability of the IKEA Mammut children's chair.

5. Place a leg cap (C) onto the wide end of a leg (B2). Be sure to align the slit in the leg cap rim (C1) with the wedge (B2A) inside the wide end of the leg (B2).
6. Repeat 3 more times until all wide leg ends (B2) are covered with a cap (C).

Note: Apply pressure to the wide leg ends (B2) to secure the legs (B) to the seat (A). But first ensure line B1A is aligned with the arrow at each leg hole (A2A).



Part II. *Hammer time.*

1. Unpack the small wooden block (D) from your IKEA package.
2. Place the block (D) on top of the flat surface of the leg cap (C). Keep it centered and still.
3. Hammer the block (D) until the narrow leg end (B1) is secure inside the hole (A2A) of the seat (A2). Watch your fingers!
4. Repeat until all four legs (B) have been hammered into the seat (A2).

Note: Ensure line B1A is aligned with the arrow at each leg hole (A2A) and that each narrow end of the leg (B1) is flush with seat side A2.

Part III. *Inserting the Backrest with Slats.*

1. Now flip the chair so that it stands on its legs. Side A1 with three slots (A1A) along one edge should be facing up.
2. Unpack the Backrest with Slats (E) from your IKEA package.
3. Insert the slats into the slots (A1A) on side A1. Ensure that the side of the slats with a protruding peg (E1) is inserted facing inside the seat.
4. Push downward from the top of the backrest until you hear a click from each slat.

Note: Just because you heard a click does not mean all three slats are secured. Check that all three slats have clicked into place.

Part IV: *Enjoy your new IKEA Mammut children's chair.*

Care instructions—Wipe clean with a soft, damp cloth and a mild non-abrasive dish detergent or soap, if necessary.

